

# Ordering the Hose That Fits Your Central Vacuum System



**VACUFLO Inlet valves**

## VACUFLO Inlet Valves

The Vacuflo Inlet Valve's low-voltage contact switches are above the valve opening. The low-voltage connection is made when the low-voltage pins on the hose are inserted into the contact switch.




**Universal Inlet valves**


## Universal Inlet Valves

The Universal Inlet Valve's low-voltage contact switches are inside the valve opening. The low-voltage connection is made when the low-voltage ring on the hose connects with the brass contact switches inside the inlet valve.

Universal Inlet Valves support electric powerheads and hoses only with a pigtail cord.



**Universal Inlet valves with pigtail**



**Direct Connect Electravale**

## Direct Connect Electravales

The Direct Connect Electravale 110V contact switches are above the valve opening. The electrical connection is made when the pins on the hose are inserted into the contact switch.

Direct Connect Electravales support electric powerheads and hoses.